
Shower Waste Instructions

90 mm Shower Trap C/W Key Installation & Assembly Instructions

A. Trap Assambly



This trap provides a flow rate grater than 32L per minute when tested in accordance with EN274-2:2002. The flow rate can be adversely affected if an adaquete fall is not maintained throughout the length of the waste pipe.

Install the trap into the shower tray by assembling 1,2,3,4 as shown

Connect the trap outlet 4 to the waste pipe making sure the pipe is supported. Test the insulation.




Please note: Check the sealing washer

Please note: Check the sealing washer (2) and position correctly. Failure to do so may result in leaks.




B. Trap Fitting



Insert the container and trap (6-7) firmly engage the trap in the bottom position

Note: If silicone sealant is used, do not use an acetocy sealant





After Care: Regular maintenance is required to reatin a high flow rate. Remove the flange (5) and trap assembly (6-7) and thoroghly clean all the parts. Rinse through the trap body with clean water and carefully reassmble the parts.

MH-01

Warning: Do not use abrasives, scourers, bleach or any type of chemical cleaning solution when cleaning the waste cap. Soapy water only should be used.