



LOWER THE TOP HEATING ELEMENT

Extract the heating element from its seating.



Then lower it.



To return the heating element to its position, lift it up, pull it slightly towards you and make sure that the tab support is in its proper seating.

